

## HW60820 Assembly Manual

## **Accent Chair**




## **A** CAUTION

THIS ASSEMBLY MANUAL CONTAINS IMPORTANT SAFETY INFORMATION.

PLEASE READ AND KEEP FOR FUTURE REFERENCE.






## Before you begin:


- 1. Check if you have received all parts using the diagram on this page. Do not start the assembly process until all parts are present. If you have not received all parts or received wrong or damaged ones, please contact our customer service and we will get back to you.
- 2. Do not discard any of the packaging until you are certain that you have all the necessary parts for the assembly.
- 3. Do NOT use power tools for assembly.



Use an Allen Wrench (I) to tighten the Screw (G) on the Backrest (A) of the Seat (B). Do not fully tighten them yet.




2 Insert the Flat Washers (H) between the Right Leg Frame (D) and the Backrest (A). Use an Allen Wrench (I) to tighten the Screw (G) on the Right Leg Frame (D) of the Seat (B) and the Backrest (A). Do not fully tighten them yet.






Insert the Flat Washers (H) between the Left Leg Frame (C) and the Backrest (A). Use an Allen Wrench (I) to tighten the Screw (G) on the Left Leg Frame (C) of the Seat (B) and the Backrest (A). Do not fully tighten them yet.




4 Turn assembled chair upright and place on a flat surface. Push legs up or down as necessary to level. Once level, tighten all screws. Note: Each leg has an adjustable foot leveler to help level your chair.





5 Then place the Seat Cushion (E) and Back Cushion (F) on the chair.



6 Assembly complete. Enjoy.

