




ASSEMBLY INSTRUCTION




LEFT PARTS LIST

A



B



C



D



E




F



G




A	SEAT BASE	1PC
B	BACKREST	1PC
C	HEADREST	1PC
D	POWER SUPPLY	1PC
E	PLASTIC FEET	2PCS
F	METAL FEET	4PCS
G	GASKETS	6PCS




LEFT PARTS LIST

There is a socket behind the Left Arm,pls plug in before using the power reclining function.




Recliner Seat Base Control


USB



Type-c




Socket with Switch: You need to turn on the Switch, so that the reclining function can use (you will see the switch on the side of arm light up).




ARMLESS PARTS LIST

A B C D E




A	SEAT BASE	1PC
B	BACKREST	1PC
C	HEADREST	1PC
D	PLASTIC FEET	4PCS
E	GASKETS	4PCS




CORNER PARTS LIST

A



B







D



E




A	SEAT BASE	1PC
B	BACKREST	2PCS
C	PLASTIC FEET	4PCS
D	GASKETS	4PCS




ARMLESS PARTS LIST

A B C D E



A	SEAT BASE	1PC
B	BACKREST	1PC
C	HEADREST	1PC
D	PLASTIC FEET	4PCS
E	GASKETS	4PCS



RIGHT PARTS LIST

A

B



C

D

E

F

G



A

SEAT BASE

1PC

B

BACKREST

1PC

C

HEADREST

1PC

D

POWER SUPPLY

1PC

E

PLASTIC FEET

2PCS

F

METAL FEET


4PCS

G


GASKETS

6PCS


C



B



A





1/2

RIGHT PARTS LIST

There is a socket behind the Left Arm,pls plug in before using the power reclining function.

Recliner Seat Base Control



Socket with Switch: You need to turn on the Switch, so that the reclining function can use (you will see the switch on the side of arm light up).

