


ASSEMBLY INSTRUCTION




LEFT PARTS LIST

A


B

C

D




A	SEAT BASE	1PC
B	BACKREST	1PC
C	LHF WING	1PC
D	POWER SUPPLY	1PC




LEFT PARTS LIST

There is a socket behind the Left Arm,pls plug in before using the power reclining function.




Socket with Switch: You need to turn on the Switch, so that the reclining function can use (you will see the switch on the side of arm light up).







ARMLESS PARTS LIST

A

B




A	SEAT BASE	1PC
B	BACKREST	1PC




CORNER PARTS LIST

A



B



A





SEAT BASE

1PC




B

BACKREST

2PCS



CORNER PARTS LIST






A	SEAT BASE	1PC
B	BACKREST	1PC
C	SCREW $\Phi 8\text{mm}$	2PCS
D	NUT FOR CONSOLE	2PCS

STEP 1: Open the storage lid to take out the Double-Thread Screws,Nuts .Unzip the non-woven cover from the bottom of the Console Base to take out the Backrest.

STEP 2: Hold up the Backrest,while standing behind,insert the Double-Thread Screws to the holes under Backrest and use your hand screwed 1/3 inside.

STEP 3:Align the both screws to the holes on the top of Console base(behind the storage lid), Place a Washer Ring on the screw and use the Nut to fix the Backrest on the Console Base,handle this process from the hind of Console Base to the inside (zip the non-woven cover after finish assembly)




RIGHT PARTS LIST

A


B

C

D



A	SEAT BASE	1PC
B	BACKREST	1PC
C	RHF WING	1PC
D	POWER SUPPLY	1PC



RIGHT PARTS LIST

There is a socket behind the Left Arm,pls plug in before using the power reclining function.

